

Mounting Instructions


Fixed Universal Screen Bracket

MD 052B1000, MD 052B1010, MD 052B2000


1

Mounting screen profiles

Mount the screen profiles to the back of the screen. Divide the profiles as well as possible.




2x



a. bolt b. washer c. cuff d. spacer

* use M4, M5, M6 or M8 mounting material (depending on flat screen) (spacers only if necessary)



top flat screen


2

Ensure there is a minimum distance of least at least 1.5 m between the wall and one side of the mounting plate, to install the locking bar at step 4.

Mounting back plate


A

Mounting back plate to the wall




B

Mounting back plate to the wall (alternative mounting positions)




C

Mounting back plate to truss



D

Mounting back plate to flat screen stand





Mounting Instructions

Fixed Universal Screen Bracket

MD 052B1000, MD 052B1010, MD 052B2000

3



Connecting flat screen to base plate



Hook on connecting profiles to the back plate

4

Transit locking bar



Transit the locking bar through the 'cheeks' of the back plate.

5

Lock (optional)

